

Can opener

Profi Can – The Original



PRODUCT DESCRIPTION

Profi Can allows you to open cans without rough edges. This comfort version for daily use has a non-slip plastic grip which ensures easy handling. Cans are opened externally at the rim of the lid, meaning that no sharp edges are formed either on the lid or the can rim. In contrast with conventional models, metal shavings do not become mixed with the can contents.

The can opener does not come into contact with the can contents. After opening, the lid can be put on once again. This means that the drying out of the can contents and build up of odors can be avoided.

TO USE

Turn the turning grip of the can opener backwards and position onto the can rim. Now turn the turning grip forwards until the can is completely opened and remove the can opener by turning the turning grip slightly backwards. Now you can remove the lid.



MERX
PRODUCTS

www.merxproducts.com

FEATUERS

- Easy to operate with low physical effort
- Safe: no sharp edges are formed
- Hygienic: The lid top and can opener do not come into contact with the can contents
- Functional: After opening the lid can be put back on again. The can contents remain fresh and odors cannot escape
- Head and grip are made from food-safe plastic

TECHNICAL SPECS

Material:	High quality plastic
Colors:	white/anthracite, lime
Size:	210 x 60 x 35 mm
Weight*:	109 g/unit
Packaging:	Blister
PU:	24 units/box
Art-No.:	◆ 100741 ● 100224
EAN:	◆ 9120017751878 ● 9120017752073

* Approx data

MERX PRODUCTS Handels GmbH
Eugen Getzner Straße 7 · 6710 Nenzing, Austria
T +43 5525 62373 · info@merxproducts.com